Monitoring Technique

VARIMETER Mains Frequency Monitor MK 9143N, MH 9143








- According to IEC / EN 60 255, VDE 0435 Teil 303
- Monitoring of 50 and 60 Hz-current supply on over- and underfrequency
- Monitoring of local generator sets and voltage supplies
- For precise frequency measuring with fast response time
- High disturbance immunity
- Separately adjustable trip points and separate outputs for overand underfrequency (1 or 2 c/o each)
- MK 9143N / MH 9143:
 - Trip points adjustable precisely and reproducible on 10 step rotational switch in the range of \pm 0,1 Hz to \pm 5 Hz related to
 - Nominal frequency 50 or 60 Hz selectable
- Fixed hysteresis optimised for trip point
- Time delay for over and underfrequency each adjustable from 0 to 20 s
- As option one common output for under and overfrequency "Window"-mode (MK 9143N/400 / MH 9143/400)
- MH 9143.38/008: with galvanic separated analogue output (current/ voltage) and 11 step LED chain for the actual frequency
- MK 9143N/600 / MH 9143/600:
- Variable alarm value in the range of 45 to 65 Hz
- Hysteresis adjustable for under- and overfrequency separately adjustable 0 ...20%
- Common output for under and overfrequency "Window"-mode can be selected
- Start up delay 0...30 s selectable
- Manual or auto reset selectable
- Output relay energized or de-energized on trip selectable for overfrequency
- Output relay de-energized on trip for underfrequency
- Universal frequency measuring input for AC 40 ... 550V
- Several options for auxiliary supply
- As option without aux. supply for voltage range AC 18 ... 70 V or 70 ... 275V
- LED indicators for auxiliary supply, input frequency, over and under frequency alarm
- 2 possible contact arrangements


MK 9143N and MK 9143N/600: 2 x 1 C/O contacts, width 22,5 mm MH 9143 and MH 9143/600: 2 x 2 C/O contacts, width 45 mm

Approval and Marking






Circuit Diagrams



MK 9143N.38


E0


E1 E2



MH 9143.38/008

Settings





Application

Monitoring of local generator sets and voltage supplies

Function

The auxiliary supply is connected to terminals A1-A2.

(If the measuring voltage is within the tolerances pf the auxiliary supply the terminals A1-A2 can also be supplied from the Measuring voltage.) The measuring input is on terminals E0-E1-E2 with low voltages on E1-E0 and high voltages on E2-E0 (see technical data). The input frequency is compared to the values set on the device.

If the input frequency falls below or rises above the tripping value, the corresponding output relay goes in alarm state (with time delay if adjusted) and the LED >f or <f lights up. When the frequency returns to good state the relays the hysteresis is active before the relays return to good state and the corresponding LED goes off.

If manual reset is selected the relay and the LED remain in alarm state when the frequency returns to good state.

Manual reset is made by bridging terminals X2-M or by disconnecting the auxiliary supply.

In de-energized on trip mode the output relay is energized in good state (contacts 11-14 etc. closed).

In energized on trip mode the output relay is energized in alarm state (contacts 11-14 etc. closed).

If start up delay is selected a timer is started after connection of auxiliary supply that disables the measuring circuit for the adjusted time. Both LEDs <f and >f flash together and the relays are in non tripped state (Good state). Using the start up delay an alarm can be avoided during start up of a generator.

Indicators

Upper LED "UH/E":

- green, when only auxiliary voltage connected to A1 - A2
- yellow/green, when measuring frequency is detected on input
- Lower LED ">f" (yellow): -On, when overfrequency is detected, flashes
- (with short pulse) when time delay is active Lower LED ,,<f" (yellow): -On, when underfrequency is detected, flashes
- (with short pulse) when time delay is active LEDs ,,>f" and ,,<f": flash together during start up delay.

Notes

Frequency measuring input

The standard frequency measuring input for Ac voltages AC 40...550V is divided in 2 ranges (40...150 V on E1-E0 and 150-550 V on E2-E0) to achieve a higher immunity against Harmonics and disturbance. If the measuring voltage is around 150 V the smaller range should be used, as it can be overloaded continuously up to 250 V. In the case of lower measuring voltages an input for AC 10-280 V E1-E0 and 20 to 550 V E2-E0 is available with slightly lower disturbance immunity. If the measuring signal is missing or if it is to low on E0-E1-E2 the upper 2 colour LED UH/E lights green. The underfrequency output is tripped in this case as well. When the input voltage is high enough on the measuring input this LED light yellow-green.

Output contacts

Relay 1 (11-12-14, and 31-32-34 on MH 9143.39) is tripped on overfrequency. Relay 2 (21-22-24, and 41-42-44 on MH 9143.39) is tripped on underfrequency.

On the variant /600the slide switch on the front can be switched to position W (window mode) in that position both relays switch on under- and overfrequency.

Relay 1 can be switched over from energized to de-energized on trip, relay 2 only operates de-energized on trip.

The model /400 operates always window mode. Both relays switch on over- and underfrequency. On this variant both relays can be switched over together between energized and de-energized on trip

Notes

Programming terminals (M - X1 - X2 - X3):

/!\

Attention! The terminals M-X1-X2-X3 have no galvanic separation to the measuring circuit, and must be operated potential free.

M: Common connection (Ground) of the programming terminals

X1: A start up delay of 0...30 s after connection of auxiliary supply is achieved by connecting a X1 to M with a potentiometer or fixed resistor (see technical data). The start up delay can be stopped by bridging X1 to M at any time.

If no start up delay is required the terminals X1-M must be linked.

Manual reset with NO contact push button on X2-M, auto reset X2: with terminals X2-M bridged.

selection of nominal frequency 50 or 60 Hz with MK 9143N and X3: MH 9143;

> selection of relay mode energized or de-energized on trip for relay 1 with MK 9143N/600 and MH 9143/600

Model MK 9143N and MH 9143:

This variant offers a very accurate frequency setting that is required e.g. for small generator sets which feed the public mains:

- the adjustment of the tripping values for over and underfrequency is accurate and reproducible in 10 steps from + / - 0,1 Hz to + / - 5 Hz
- the hysteresis is always 1/8 of the adjusted tripping value. I. e. at setting + or -0,1 Hz it is 0,012 Hz and at setting + or -4 Hz it is approx. 0,5 Hz
- the tripping delay is separately adjustable for over and underfrequency with a range of 20 s.
- switching between energized and de-energized on trip of relay 1 by slide switch Rel.1 on the front
- programming of mains frequency 50 or 60 Hz with terminal X3:

X3 open: Frequency 50 Hz X3 linked to M: Frequency 60 Hz

Variant MH 9143.38/008: 45 mm width

Identically to MK 9143N, but with 11 step LED chain indicator and galvanic separated analogue output to display the difference between measured frequency and the mains frequency (50 or 60 Hz).

On terminals U/G of the analogue output 0-10 V are provided, on terminals I/G 0-20 mA are available. By bridging terminals Y1 and G the output can be switched over to 2-10 V and 4-20 mA. The middle value of the analogue output indicates nominal frequency, the display and analogue output shows \pm 10% difference to the nominal frequency.

Model MK 9143N/400 and MH 9143/400

Identical with MK 9143N and MH 9143 but both output relays switch together (Window mode) and both can be switched over together via slide switch from energized to de-energized on trip.

Model MK 9143N/600 and MH 9143/600

To be used on local generator sets and other equipment where larger frequency tolerances are necessary:

- Adjustment of the tripping values for over and underfrequency individual between 45 and 65 Hz
- Separate adjustable hysteresis for over and underfrequency in a range of 0,5 ... 20% of the tripping value
- Output function can be changed with slide switch (S1)on the front:

Position "N": Normal mode: relay 1 for overfrequency, relay 2 for underfrequency

Window mode: relay 1+2 switch together at over and Position "W": underfrequency

- Switching between energized and de-energized on trip of relay 1 by slide switch Rel.1 on terminal X3:

X3 open: de-energized on trip for relay 1 X3 linked to M: energized on trip for relay 1

Adjustment aid for start up delay and alarm delay

During the elapse of start up delay and alarm delay on MK 9143N and MH 9143) the yellow LED <f or >f is flashing with a frequency of 2 Hz. To set a specific time value in seconds the number of flash pulses can be used to check the setting: Number of flash pulses divided by 2 = time delay in seconds.

Technical Data

Measuring Input (E0-E1-E2)

Voltage range

E0-E1: AC 40 ... 150 V, E0-E2: AC 150 ... 550 V

Input resistance

F0-F1: approx. 170 k Ω E0-E2: approx. 640 k Ω

Galvanic separation: Frequency measuring input to auxiliary

voltage and output contacts

Response time of

typ. 60 ms Frequency monitoring:

(when alarm delay is 0)

Time between connection of auxiliary supply and

ready to mesure: approx. 0,4 s (with start up delay is 0) Start up time delay: adjustable from 0 ... 30 s with

resitor/potentiometer between

terminals X1 and M:

R / kΩ:	0	4,7	12	22	39	56	100	180	390	∞
t _{Anı} / s:	0	0,5	1	2	4	6	10	15	20	30

Adjustment of the response values (frequency threshold

for alarm)

MK 9143N, MH 9143: 10 individual step as deviation from

nominal frequency.

- 1	overfrequency:								l	ı	ı	
	underfrequency:	-0,1	- 0,2	- 0,5	-1	-1,5	-2	- 2,5	- 3	- 4	- 5	Hz

Setpiont frequency: 50 or 60 Hz, selectable via

connection of terminal X3

Accuracy of the better than 200 ppm (0,02 %) frequency threshold:

Auxiliary voltage- and

temperature influence: less than 200 ppm (< 0,02 %) 1/8 of adjusted deviation value of Hysterese:

nominal frequency

separately adjustable for over- and Time delay:

under frequency alarm: 0 ... 20 s adjustable on logarithmic scale.

Adjustment of response value (frequency threshold

for alarm)

MK 9143N/600, MH 9143/600: continously variable, separately for over-

and underfrequency alarm: each 45 ... 65 Hz

Setting accurancy: approx 1 Hz

Hysteresis: continously variable, separately for overand underfrequency alarm: each 0,5 \dots 20 %

of the setting alarm threshold

Tolerances of the adjusted tripping values at variation of auxiliary supply and

temperature: ± 0,2 Hz

Auxiliary Circuit

Auxiliary voltage U

(galvanic separation): AC 115, 230, 400 V

DC 12, 24, 48 V

AC/DC 24 ... 60, 110 ... 230 V (only for

MH-version possible)

Voltage range:

0,8 ... 1,1 U_H AC: DC: 0,9 ... 1,2 U AC/DC: 0,75 ... 1,2 Ü

Frequency range

45 ... 440 Hz AC:

Nominal consumption:

AC: approx. 4 VA DC: approx. 2 W

Technical Data

Output 11-12-14, 21-22-24; + 31-32-34, 41-42-44 at MH 9143.39

Contacts

MK 9143N.38, MK 9143.38/600: 2 x 1 C/O contacts, each 1 for

over- and underfrequency alarm

MH 9143.39, MH 9143.39/600: 2 x 2 C/O contacts, each 2 for

over- and underfrequency alarm

Thermal current I,:

Switching capacity according to AC 15

NO contact: 3 A / AC 230 V IEC/EN 60 947-5-1 NC contact: 1 A / AC 230 V IEC/EN 60 947-5-1

according to DC 13

NO contact: 1 A / DC 24 V IEC/EN 60 947-5-1 NC contact: 1 A / DC 24 V IEC/EN 60 947-5-1

Elektrical life

acc. to AC 15 at 1 A, AC 230 V: 1,5 x 105 switching cycles IEC/EN 60

947-5-1

Short circuit strength

max. fuse rating: 4 A gL IEC/EN 60 947-5-1

Mechanical life: 30 x 106 switching cycles

Analogue Output with MH 9143.38/008

galvanic separation AC 3750V

to auxiliary supply, measuring circuit and relay outputs.

terminal U(+) / G(-): 0 ... 5 ... 10 V, max. 10 mA 0 ... 10 ... 20 mA, max. burden 500 Ohm terminal I (+) / G(-):

change to 2 ... 10 V or 4 ... 20 mA by bridging terminal Y1 and G

Analogue output: ± 10% difference to the nominal frequency

General Data

Nominal operating mode: continuous operation Temperature range: - 20 ... + 60°C

Clearance and creepage distance

rated impuls voltage /

pollution degree:

output to measuring circuit: 4 kV / 2 IEC 60 664-1 output to auxiliary circuit: 4 kV / 2 IEC 60 664-1 output to output to: 4 kV / 2 IEC 60 664-1 auxiliary circuit to

4 kV / 2

measuring input: Programming terminals

M-X1-X2-X3: without galv. separation to measuring circuit

EMV

Electrostatic discharge (ESD): 8 kV (air) IEC/EN 61 000-4-2 Fast transients: 4 kV IEC/EN 61 000-4-4

Surge

between

wires for power supply: IEC/EN 61 000-4-5 1 kV between wire and ground: 2 kV IEC/EN 61 000-4-5 HF-wire guided: IEC/EN 61 000-4-6 30 V Interference suppression: Limit value class B EN 55 011

Degree of protection:

IP 40 IEC/EN 60 529 Housina: **IP** 20 Terminals: IEC/EN 60 529 thermoplastic with V0 behaviour

Housing: according to UL subject 94 Vibration resistance:

Amplitude 0,35 mm

Frequency 10 ... 55 Hz IEC/EN 60 068-2-6 Climate resistance: 20 / 060 / 04 IEC/EN 60 068-1 Terminal designation: EN 50 005

Wire connection: 1 x 4 mm² solid or 2 x 1,5 mm² solid or

1 x 2,5 mm² stranded wire with sleeve

DIN 46 228-1/-2/-3/-4 or

2 x 1,5 mm² stranded wire with sleeve DIN 46 228-1/-2/-3/

Plus-minus terminal screws

Wire fixing:

M4 box terminals with wire protection DIN rail IEC/EN 60 715

Mounting: Weight: MK 9143N. MK 9143/600:

approx. 210 g MH 9143, MH 9143/600: approx. 295 g MH 9143.38/008: approx. 350 g

Dimensions

Width x heigh x depth:

MK 9143N, MK 9143/600: 22,5 x 90 x 97 mm MH 9143, MH 9143/600: 45 x 90 x 97 mm

IEC 60 664-1

Standard Type

MK 9143N.38 $\,$ + / - 5 Hz $\,$ U $_{\rm H}$ AC 230 V Article number: 0060

Article number: 0060936

• Each 1 C/O contact for over- and underfrequency

Auxiliary voltage U_H:
 AC 230 V

Frequency measuring input: AC 40...150 / 150...550 V

• Trip points adjustable precisely and reproducible on 10 step rotational switch in the range of \pm 0,1 Hz to \pm 5 Hz related to 50 or 60 Hz

• Switching setpoint frequency: 50 / 60 Hz

Time delay for over and underfrequency each adjustable from 0... 20 s

Start up delay: 0...30 s selectable

· Manual or auto reset selectable

• Width: 22,5 mm

Variants

MK 9143N.38/400: as MK 9143N.38, but with

output relay in "Window"-Mode

MK 9143N.38/600: - over- and underfrequency threshold

each continously variable of 45 ... 65 Hz

- without time delay

 Hysteresis at over- and underfrequency each continously variable of 0,5 ... 20 %

- Funktion mode of the outputrelay

switchable on "Window"

MH 9143.38/008: similar to MK 9143N.38, but with galvanic

separated analogue output (current/voltage)

and 11 step LED chain.

Width: 45 mm

MH 9143.39: as MK 9143N.38, but with each

2 C/O contacts for over- and underfrequency

width 45 mm

MH 9143.39/400: as MK 9143N.38/400, but with each

2 C/O contacts for over- and underfrequency


width 45 mm


MH 9143.39/600: wie MK 9143N.38/600, but with

2 C/O contacts for over- and underfrequency

width 45 mm

Ordering example for variants





E. DOLD & SÖHNE KG • D-78114 Furtwangen •	• PO Box 1251 • Telephone (+49) 77 23 / 654-0 • Telefax (+49) 77 23 / 654-38	56